## **Water Chiller**

# TT-28'500

Air cooled water chiller with integrated heating capability for the water circuit Mobile unit for individual machines or multi-machine applications

For water temperatures from +10°C up to +40°C, at ambient temperatures up to +45°C

Suitable for high ambient air and tropical installations

No unnecessary water consumption due to a closed water circuit






## Operating principle

The unit is equipped with a corrosion free water tank with a content of approx. 150 litres. The cooling compressor cools the water content to the required temperature. The resultant heat leaves the unit through the cover and the side panels. Should the water temperature be too low, the heating element will be activated automatically.


- Self-optimizing microprocessor controller with digital display of the set and actual temperature. With high precision regulation in <sup>1</sup>/<sub>10</sub>° range; can be adjusted to read °C or °F.
- Digital flow indication with control of the minimum flow.
- All components in contact with water are made of corrosion resistant stainless steel.
- Long life expectancy due to the electronic control of the compressors operating time.
- If the water in the system does not reach the required temperature, the built-in heating will be activated automatically.
- Automatic or manual water refill.
- Automatic level control with prewarning at low water level.
- Horn in case of failure.
- · All failures are visually indicated.
- · Unit on castors.



## **Pump capacity**



#### Cooling capacity



#### **HEADQUARTERS & MANUFACTURER**

SOL-IEMP

#### **Technical data**

self-optimizing, electronic microprocessor controller MP-888 with Temperature control

digital display of the set and actual value.

Automatic temperature monitoring.

Flow control electronically, with digital display and automatic control of the

minimum flow.

Cooling capacity

Nominal 28 kW - see diagram

Temperature range

Circulating water +10°C up to +40°C +2°C up to +45°C Air temperature

Heating 9 kW, manual switchable

Content water tank approx. 150 I

Refrigerating agent R-134a

max. 5 bar / max. 145 l/min - see pump diagram **Pump capacity** 

Compressor hermetically sealed

Condenser air cooled, air inlet located on the rear, blow out located on the side/top

Air volume 5'700 m<sup>3</sup>/h (not relevant to WK)

**Power consumption** approx. 11,3 kW (heating mode approx. 11,3 kW, cooling mode approx. 6 kW)

**Connections** 

To / from mould 1" BSP female thread 3/8" BSP female thread Automatic water refill Drain 1/2" BSP female thread

Cooling water inlet 3/4" BSP female thread (only at WK) Cooling water outlet 1" BSP female thread (only at WK)

**Dimensions (L×W×H)** 1'100 × 790 × 1'660 mm, incl. castors

68 dBA Noise level (in 3 m distance)

Weight 330 kg empty

Colour silvergrev RAL 7001

optional: stainless steel case, not varnished

#### TT-28'500 WK:

The same model is also available as water cooled version. Required cooling water: minimum 1,5 bar water pressure.

With cooling tower water (approx. 30°C) approx. 30 - 50 l/min cooling water consumption With tap water (approx. 10 - 15°C) approx. 20 - 25 l/min cooling water consumption

#### **Electronic temperature controller MP-888**

The electronic controller can be adjusted to indicate °C or °F. The upper turning on point and lower turning off point (hysteresis) of the temperature band can be adapted. Due to this, the time range between the start and stop point of the compressor is wider and the compressor has a longer life expectancy.



Set temperature / required temperature Adjustable in 1/10° range

Actual temperature (effective temperature) displayed in <sup>1</sup>/<sub>10</sub>° range Indication of flow with <sup>1</sup>/<sub>10</sub> display. Switchable from liter to English

or American gallons. As soon as the flow falls below a minimum, the alarm is activated.

Flow control with automatic or manual pre-adjusted mode:

Automatic: The electronic flow control measures the actual flow, generates automatically a minimum flow and as soon as the flow falls below this value, the alarm will be activated.

Manual: The minimum flow can be adjusted manually. As soon as the flow falls below this value, the alarm will be activated.

#### ASIA SUBSIDIARY

Tel.: 0065 6848 0768 Fax: 0065 6542 2064 E-Mail: ttsales@tooltemp-asia.com.sg

Internet: www.tool-temp.asia

